



Set precise torque & angle tolerances using - Preset Torque & Angle mode



Audit residual torque with Just Move mode



TAW***

AUDITOR digital wrench

Basic specification

- Accuracy $\pm 1\%$ actual reading for torque, ± 1 degree for angle.
- 1-2000Nm range across TAW*** series.
- Designed, tested & calibrated as per ISO 6789.
- Full colour OLED screen.
- Measurement modes of operation: **Track** current torque, capture **Peak** torque, configure torque or torque & angle **Presets**, test residual torque with **Just Move** mode.
- Supplied with 3 angle modes as standard.
- Comes with PC software included. Download measurements, lock wrench modes, analyse data (SPC), graph results.
- Wireless communications available.

TRACEABILITY

Fully traceable calibration certification

Capture the actual installed torque & angle

COMPLIANCE

Residual torque audits validate the integrity of an assembly, highlight defects & reduce product recalls

PRODUCTIVITY

Control the assembly process with precise tolerances for Torque & Angle

Torque it right first time, every time!

Contact our team today!

+353 61 331522

info@bmsireland.com

www.bmsireland.com

